Dear Customer,

You have just acquired a ***DE DIETRICH*** *dishwasher and we would like to thank you.*

Our research teams have created this new generation of appliances for you. Their quality, design, features and technological advances make them exceptional products, and reveal our unique know-how.

Your new ***DE DIETRICH*** *dishwasher will blend harmoniously into your kitchen and will perfectly combine washing and drying performance and ease of use. We wanted to offer you a product of excellence.*

In the ***DE DIETRICH*** *product range, you will also find a wide choice of hobs, ovens, microwaves, hoods, cookers, fridges, freezers, that you can coordinate with your new* ***DE DIETRICH*** *dishwasher.*

Visit our website ***www.dedietrich-electromenager.com****, where you will find our latest innovations as well as useful and complementary information.*

DE DIETRICH
Setting New Values

As part of our commitment to constantly improving our products, we reserve the right to make changes to them based on technical advances to their technical and functional features and appearance.

Warning :
Before installing and using your appliance, please carefully read this Guide to Installation and Use, which will allow you to quickly familiarise yourself with its operation.

www.dedietrich-electromenager.com

EN **CONTENTS**

1/ FOR THE USER'S ATTENTION
- Safety instructions ____ 36
- Environmental protection ____ 37
- Economical, environmentally friendly washing ____ 37

2/ DESCRIPTION OF YOUR APPLIANCE
- General presentation of the dishwasher ____ 38
- Presentation of the control panel ____ 39

3/ INFORMATION ____ 40

4/ WHAT TO DO BEFORE FIRST USING THE MACHINE
- Measure the water hardness and select the type of detergent ____ 41
- Hardness table ____ 41

5/ DETERGENT PRODUCTS AND ADJUSTING THE WATER SOFTENER
- For traditional products ____ 42
- For multi-purpose products ____ 43

6/ LOADING OF REGENERATING SALT ____ 44

7/ LOADING OF RINSING PRODUCT ____ 45

8/ YOUR DISHWASHER'S EQUIPMENT
- The lower basket ____ 46
- The upper basket ____ 47
- The cutlery basket ____ 48

9/ SETTING THE PARAMETERS ____ 49

10/ WASHING PROGRAMMES ____ 50

11/ PROGRAMMING ____ 52

12/ CLEANING YOUR APPLIANCE
- Cleaning the waste filters ____ 53

13/ YOUR DISHWASHER'S SAFETY SYSTEMS ____ 55

14/ IF OPERATING ABNORMALITIES OCCUR ____ 56
- Changing the bulb ____ 61

15/ AFTER-SALES SERVICE ____ 62

16/ INDICATIONS FOR THE TESTING LABORATORIES ____ 63

Important :

Keep this user's manual with your appliance. If the appliance is sold or transferred to someone else, ensure that the manual is with it. Please take note of these instructions before installing and using your appliance. They have been drawn up for your own and other people's safety.

• SAFETY INSTRUCTIONS

• Installation

– When you receive your appliance, unpack it or have it unpacked immediately. Check that it has not suffered any damage during transport. Express any reservations in writing on the delivery note, of which you keep a copy. Never connect up a damaged machine. If your appliance is damaged, please contact your dealer.
– Before proceeding to connect up your machine, please refer to the instructions in your Installation Guide.
– Your dishwasher must be kept disconnected from the mains supply throughout the whole of the installation process.
– The electrical connection details on your appliance's description plate must comply with those for the mains supply.
– The socket must still be accessible once your appliance has been installed.
– Do not alter or attempt to alter the appliance's characteristics. This could put you at risk.
– If your installation has to be altered, only entrust the electrical and plumbing work to a qualified electrician or plumber respectively.
– Your appliance is designed for normal domestic use. Do not use it for industrial or commercial purposes or for any other purpose than that for which it has been designed.
– The dishwasher's walls must not be pierced under any circumstances.

• Children's safety

– This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
– This appliance must only be used by adults. Ensure that children do not touch it and do not use it as a toy. Ensure that they do not operate the appliance's controls.
– Keep young children away from the appliance when it is operating.
– Detergents contain irritant and abrasive substances. These products can have caustic effects on the eyes, the mouth or the throat. They can be extremely dangerous if ingested. Avoid any contact with the skin and the eyes. Ensure that the appliance's detergent container is empty at the end of the washing cycle.
– Place detergents out of children's reach and do not put any detergent in the machine until just before you start the washing programme.
– The water in your dishwasher is not drinking water; this is why children must not go near the appliance when its door is open.
– Do not let your children play or sit on the door when it is open.
– Once you have unpacked your appliance, place the packaging out of children's reach.
– Keep all the packaging materials (e.g. plastic bags, polystyrene, etc.) out of children's reach because they can be dangerous for children (ie. risk of suffocation).

• Use

– This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
– When machine is running, do not open door. This may provoke steam leakage or splattering of water.

– Only use products specially designed for your dishwasher (water softening salt, detergent and rinsing products).
– As far as possible, avoid opening the dishwasher's door when it is operating, and in particular during the heating phases, because scalding steam may escape or you may be splashed with hot water. The machine is fitted
with a safety system that immediately blocks the dishwasher's operation if the door is opened.
– Never use chemical solvents in your appliance because these could cause an explosion.
– Always close your appliance's door after loading or removing your items.
– Do not lean or sit on your appliance's door when it is open.
– You are strongly advised to disconnect the machine after use and turn off the water supply.
– Unplug your machine before carrying out any technical work on it.
– Avoid placing your machine immediately next to a cooking or heating appliance to prevent any risk of heat damage;
– Do not place any items in your machine, which are not certified as dishwasher safe.
– If you have removed an item before the end of the washing programme, it is important to rinse it carefully to remove any residual washing products.
– If your appliance breaks down, never attempt to repair it yourself. Any repairs made by non-qualified personnel can cause significant damage or lack of control.
– The machine complies with applicable safety regulations. Any repairs should be carried out by qualified technicians. Repairs or changes that do not conform may be dangerous for the users. In case of replacement, only use original parts.
– If the machine malfunctions due to other causes than those mentioned in this booklet, disconnect the machine (remove the plug) or break the circuit concerned and contact after-sales service.

• *ENVIRONMENTAL PROTECTION*

This appliance's packaging material is recyclable. Help recycle it and protect the environment by dropping it off in the municipal receptacles provided for this purpose.

Your appliance also contains a great amount of recyclable material. It is marked with this label to indicate that in countries that are a members of the European Union the used appliances should not be mixed with other waste. This way, the appliance recycling organised by your manufacturer will be done under the best possible conditions, in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment. Contact your town hall or your retailer for the used appliance collection points closest to your home.
We thank you doing your part to protect the environment.

• *ECONOMICAL, ENVIRONMENTALLY FRIENDLY WASHING*

– Remove any food residue from your crockery (bones, pips, etc.)
– Do not pre-wash your items by hand (useless waste of water).
– Utilise your dishwasher's capabilities to the full for an economical, environmentally friendly wash.
– Always select a washing programme suitable for the crockery type and how dirty they are.
– Avoid overdosing with detergent, regenerating salt and rinsing liquid. Follow the recommendations in this guide (pages 43-44-45) and the instructions on the product packs.
– Ensure that the water softener is correctly set (see pages 42-43).

• *GENERAL PRESENTATION OF THE DISHWASHER*



Fig. 01

- **A** ***Upper basket***
- **B** ***Washing products dispenser***
- **C** ***Anti-blocking gauge wire***
- **D** ***Lower sprinkler arm***
- **E** ***Regenerating salt tank***
- **F** ***Waste filter***
- **G** ***Main filter***
- **H** ***Rinsing product dispenser***
- **I** ***Description plate (After-Sales Ref)***
- **K** ***Internal-lighting bulb (according to model)***

Advice:
This user's guide is applicable to several models. There may be some slight differences in the details and the equipment between your appliance and the descriptions provided here.

• *PRESENTATION OF THE CONTROL PANEL*



Fig. 02

A ***On/Off:***
Press this button to start your dishwasher.

B ***Choosing a programme:*** briefly press one button or the other in succession to select your programme.

C ICS ***: Intelligent Control System***
press this button to select the Automatic programme.

D ***Set:*** (see para. 9, adjustment of settings) Holding down the **"Set"** button brings up the settings menu;
- choice of language,
- Set the water softener,
- Activate or deactivate the "Regenerating Salt" and/or "Rinsing Product" lights, or the "TABS AUTO" function (depending on the water softener setting on the following pages).
- Beep at end of programme,
- Set screen brightness.

E ***Choice of delayed-start washing:***
Press this button ◷ to delay the programme by 1 to 12 hours.

F ***Start/Cancel:*** Briefly press this button to start your programme.
If you make an error, to cancel a selection or cancel a programme while it is running, hold down this button for 3 seconds.

The indicator lights:

Salt:
When lit, it indicates lack of regenerating salt

Rinsing liquid:
When lit, it indicates lack of rinsing product

AUTO 4/1 ***Multipurpose products:***
lit; shows you that the "TABS AUTO" feature is turned on and that the programmes are now automatically adjusted if a multi-function tablet is used.

↦ ***Current programme:***
on: shows current programme.

The front display screen:
Displays the current time, the programme end time, the time remaining and the warning lights.

Advice:
A short audible signal (beep) confirm the button's selection, except for the "On/Off" button. In the interests of energy conservation, the front display light goes off after the dishwasher has been inactive for a given time.
To ease loading, the dishwasher's internal light comes on when the door is opened and goes off when you push or close it, regardless of the position of the On/Off switch.

Important:
To obtain impeccable washing and drying results from your dishwasher without any marks, you must set it carefully using the water softening system, which utilises regenerating salt.

As rainwater infiltrates into the ground it picks up mineral salts; some minerals are found in solid form and are commonly called 'lime'. This reduces the detergent's washing performance and leaves white marks on the crockery.
The more lime there is in the water, the 'harder' the water is.

- Use the most suitable washing products for the hardness of your town's water supply.
- There are several types of products:

For an impeccable clean, opt for using traditional products together:

① ***Washing product*** for a perfect clean (standard powder, liquid or tablets).

② ***Regenerating salt*** for your dishwasher's water softener to work correctly.

③ ***Rinsing liquid*** to assist drying and eliminate drip marks.

Important:
Never use normal washing-up liquid.

For ease of use <u>and in certain water hardness conditions only (< 25°F), multi-purpose products</u> can make the use of regenerating salt and rinsing liquid unnecessary.

- ***"Two-in-one" tablets*** contain detergents and rinsing liquid or an agent serving the function of the salt.
- ***"Three-in-one" tablets*** contain detergents and rinsing liquid as well as an agent serving the function of the salt.
- ***"Four-in-one" "Five-in-one" tablets...*** also contain additives that prevent wear on poor quality glasses or the risk of stainless items corroding.

Important:
Follow the instructions in the user's manual and the recommendations on the multi-purpose detergent's pack.

NB:
If in any doubt, please contact the detergent's manufacturer if the items are very wet at the end of the programme or if chalky deposits appear.

• *MEASURE THE WATER HARDNESS AND SELECT THE TYPE OF DETERGENT: TRADITIONAL OR MULTI-PURPOSE*

In one simple action, you can test the your water's lime content using the testing strip supplied with your dishwasher. Alternatively, contact your local water utility to ascertain your water's hardness.

– Let the water run from the tap for a few moments.
– Fill a glass with water.
– Take the test strip from its holder and immerse it for 3 seconds.
– Wait 1 minute, shake it and look at the colours to ascertain your water's hardness.

• *HARDNESS TABLE*

Test strip	□□□□□	■□□□□	■■□□□	■■■□□	■■■■□	■■■■■	■■■■■
Hardness	0-10°F	10-18°F	18-25°F	25-40°F	40-55°F	55-70°F	> 70°F
Water	Soft	Slightly hard	Slightly hard	Hard	Hard	Hard	Very hard
Water softening and use of salt	Optional	Essential if using traditional products	Essential if using traditional products	Mandatory	Mandatory	Mandatory	Mandatory



❶ **Traditional products:** **P** : **P**owder detergent or **L** : **L**iquid detergent or single tablet
+ **S** : Regenerating **S**alt + **R** : **R**insing product

❷ **Multi-purpose products:** Multi-purpose tablets

• *FOR TRADITIONAL PRODUCTS*

• *Your machine must be specially adjusted to use traditional products.*

• *Proceed as follows to adjust the water softener on the control panel:*

– Access the settings menu by holding down the "SET" button. Then briefly press twice times to adjust the softener.



– This is then displayed on the screen from H0 to H6. The softener factory setting is H4.
– To change this setting (according to water hardness), briefly press on one of the < > , repeatedly. The screen will display the setting:
– Confirmation is automatic after about 10 seconds. Otherwise press **"SET"**.
– You can turn off the settings menu at any time by pressing the **"Start/C"** button ◇

Testing strip	□□□□□	■□□□□	■■□□□	■■■□□	■■■■□	■■■■■	■■■■■
Hardness	0-10°F	10-18°F	18-25°F	25-40°F	40-55°F	55-70°F	> 70°F
Traditional product	H0	H1	H2	H3	H4	H5	H6

Important:
It is very important to set the water softener correctly.
- If the setting is too low, there is the risk of chalky marks appearing.
- if the setting is too high, there is the risk of causing clouding of the glasses.

If you relocate, adjust the water softener setting as required.

• *Traditional tablets*

Non-multipurpose tablets should be placed in the external compartment (Fig 04) or, for optimum performance, pull out the dispenser drawer and lay the tablet inside (Fig 05).

• *Powders or liquids (Fig 03)*

Fill at least up to the minimum mark for slightly dirty crockery and to the maximum mark for dirty crockery. If the crockery is very dirty and for programmes with a pre-wash we recommend that you add 5g of detergent (a dessert spoonful) into your dishwasher's tub in accordance with the programmes table.

Important:
Keep these products out of children's reach and away from dampness.
Only use products specially designed for dishwashers.


Fig. 03


Fig. 04


Fig. 05

• *FOR MULTI-PURPOSE PRODUCTS (Water hardness < at 25°F)*

• *Your appliance automatically adapts to using multipurpose products when the water hardness is < 25°F.*

• *Proceed to set the water softener*

– This feature is adjusted using the **"SET"** ; button; hold down this button to access the menu. Then press twice to set the softener level.
– The softener level is then shown on the screen from H0 to H6. The default level is H4.
– **In order to use multi-function tablets, you need to adjust the setting.** To do this, press either arrow button < > several times until you have selected H0 or H1 or H2 depending on the water hardness.

• *Proceed to set the "TABS AUTO" function (optional)*

– Hold down the "SET" button until the "**TABS AUTO**" light flashes, then press one or other of the selection buttons < > .

– OFF :deactivates the "**TABS AUTO**" option.

– On : corresponds to activation of the "**TABS AUTO**" function with the setting for **"Sparkling Clean". This enables you to prioritise a brilliant finish for your crockery.**
– On : corresponds to activation of the "**TABS AUTO**" function with the setting for **"Extra Dry"**. **"Extra dry" enhances the drying results if performance is reduced.**
– The setting is validated automatically after 10 seconds if the *"SET"* button in not pressed again.
– The "**TABS AUTO**" light then illuminates permanently if this option has been selected.

Testing strip			
Hardness	0-10°F	10-18°F	18-25°F
Multi-purpose products Function Deactivated	H0 OFF	H1 OFF	H2 OFF
Multi-purpose products Sparkling Clean	H0 On	H1 On	H2 On
Multi-purpose products Extra Dry	H0 On	H1 On	H2 On

• *Loading the multi-purpose tablet dispenser*

To assist in loading the detergent, the distributor is situated on the front of the upper basket. It is compatible with all the products recommended for dishwashers.

• ***Place the tablet*** in the external compartment (Fig 04 on previous page) or, for optimum results, pull out the distributor's drawer and lay the tablet inside (Fig 05 on previous page).
- Close the dispenser.

• *Loading of regenerating salt (Fig 06)*

Important :

Only use special dishwasher regenerating salt. Do not use table salt or any type of cooking salt, this could damage your appliance's water softener.

Ⓐ Unscrew and remove the stopper on the salt tank.

Ⓑ Fill the tank with regenerating salt specially designed for dishwashers.

Ⓒ Use the funnel supplied with your dishwasher. The first time, top up with water up to the rim of the tank.

• *Regenerating salt indicator:*

This illuminates when salt must be added. After the tank has been filled with regenerating salt, the indicator light may remain lit until the salt has dissolved sufficiently, usually after one cycle (of if the tank has not been filled completely; for example, when first putting the machine into service using the sample).
It may be deactivated when using multifunction tablets (see para.9, Adjusting the settings).



Fig. 06

Important

If the salt overflows when filling the tank, to avoid oxidization of the tub it is advisable to remove the salt crystals or to run a Prewash programme (or Rapid programme - depending on the model).

• *Loading of rinsing product (Fig. 07)*

Important :

Only use a rinsing product designed for dishwashers. The rinsing product ensures your items shine and are well dried.

Ⓐ Ⓑ When first putting the machine into service, fill the tank until the level is flush with the top of the adjustment lever. Pour in at least all the rinsing product provided.

The original setting is 2.
After several cycles and if drying is incomplete or there are stains, we recommend increasing the setting by turning the knob (fig 07 Ⓒ) to position 3.

- Close completely.

Tip::

Position 1 reduces the amount of rinsing product needed and may be sufficient for your use.

• *Rinsing liquid indicator light:*

This illuminates when rinsing product is required.
It may be deactivated when using multifunction tablets (see para. 9, Adjusting the settings).



Fig. 07 Adjustment lever

Important :

If any of the product overflows during filling, sponge up the excess to avoid producing foam.

Very important

Items not suitable for washing in a dishwasher:

- Wooden cutting boards
- Stainless steel utensils or plastic utensils that are not heat-resistant
- Copper or pewter items
- Glued crockery and cutlery
- Cutlery with wooden, horn or mother-of-pearl handles
- Antique or hand-painted porcelain

When purchasing crockery, glasses or cutlery, ensure that it is dishwasher-safe

• *THE LOWER BASKET*

Arrange your items so that the water can circulate freely and spray over all the utensils.
Place large diameter dishes and pans at the sides.
Do not intersperse, jam together or superimpose flat plates and concave dishes (Fig. 08).
The flexible racking spikes makes it easier to arrange your large dishes (Fig. 09).


Fig. 08

Advice:

When you re-insert the lower basket, ensure that nothing catches on the oversize plate barrier to avoid blocking the rotating spray arm.

Unloading your items

Empty the lower basket to avoid drips from the upper basket falling onto the lower basket.


Fig. 09

• *THE UPPER BASKET*

This basket is particularly designed to take glasses, cups, ramekins, small salad bowls, bowls and saucers.
Arrange your items methodically to save on space (arranging glasses, cups or bowls together).
You can also arrange cups, ladles, etc. on the folding cup racks (Fig. 10)

Advice:
Position the cavities of glasses, cups or bowls facing downwards.



Fig. 10

• Adjusting the height of the upper basket

For large dishes to be loaded in the lower basket, the upper basket must be set the to high position. This can be done with the basket fully loaded (Fig. 11)

① Setting in HIGH POSITION:
Gently raise your basket on each side until it engages.

② Setting in LOW POSITION:
Raise your basket completely on both sides to unlock it and then lower it to the low position.



Fig. 11

Important :
Check that the two slides are set to the same height and the basket is horizontal.

• *THE CUTLERY BASKET*

The cutlery basket slides to allow flexible loading.
It can be placed anywhere in the lower basket. You can therefore make a variety of loads depending on the items (Fig. 12).

If your cutlery items or your dishes are too large, alter the height setting for the upper basket.


Fig. 12

Movable grills are available for if you wish to load your cutlery in an orderly manner (Fig. 13).
For optimum washing and drying, use these separation grills partially or totally.

Point the handles on the cutlery downwards.


Fig. 13

Important :
For safety reasons, we recommend that you place knives with pointed ends with the point facing downwards in the cutlery basket (to avoid the risk of an accident).
Long-bladed knives and other sharp kitchen utensils must be placed flat in the upper basket.

Avoid washing cutlery with horn handles in your dishwasher.
Separate silverware from other metals using the separation grill.

• *SETTINGS POSSIBLE WITH "SET" AND SELECTOR BUTTONS:*

- *Holding down the SET button gives access to the settings menu*
- *Adjust the parameters using the programme selector buttons* < >
- *Briefly pressing the "Set" button takes you to the next setting.*

> Setting the time (hour)

As above, press one of the selector buttons to set the hour.

> Setting the time (minutes)

As above, press one of the selector buttons to set the minutes.

> Setting the water softener

Set to the level corresponding to the hardness of your water: H0 to H6.

> Product use

You can cancel display of the relevant indicators, depending on the products used:

- Salt Set to OFF if you do not use salt or f you are using multi-purpose tablets.
- Rinsing product Set to OFF if you do not use a rinsing product or if you are using multi-purpose tablets.



> Multifunction tablets TABS AUTO

For optimum product efficiency, it is important to set the softener correctly (see para. 5 Washing products and softener setting). Adjust :

OFF desactivation of function " TABS AUTO "

On activation of function " TABS AUTO " **"completely dry" (by default)**

On activation of function " " **"Sparkling clean"**

> Beep at the end of the programme

On to activate the function; OFF if you do not wish not to hear the beep at the end of the program.

> Screen brightness

Set the screen brightness to suit yourself from Lu1 minimum to Lu5 maximum.

Advice:

The setting is confirmed automatically when you move on to the next parameter or if the "Set" button is not pressed again within the next 10 seconds.

• *PROGRAMMES TABLE*

ITEM TYPE (porcelain, pans, cutlery, glasses)	Resistant	Mixed	Mixed
FOOD RESIDUE: Quantity, type and amount	**Very dirty** A large amount of dried-on residue, baked-on stains, grease, residue from frying, cooked cheese, sauce, etc.	**Normally dirty** A normal amount of dried-on and greasy residue on everyday items. Faster, but consumes more energy.	**Normally dirty** A normal amount of dried-on, adhering residue on everyday items.
PROGRAMMES	*BOOST*	**Normal**	*ECO*
PROGRAMME SEQUENCE	Hot pre-wash Washing at 70°C Rinse Hot rinse Drying by condenser	Pre-wash Washing at 65°C Rinse Hot rinse Drying by condenser	Pre-wash Washing at 55°C Rinse Hot rinse Drying by condenser
As an indication only:			
Duration in min **Water (L)** **Energy (Kwh)**	120' - *140'* 17 - *19* 1,7 - *1,8*	90' - *120'* 17 - *19* 1,5 - *1,6*	130' - *150'* 17 - *19* 1,3 - *1,4*

WASH

These values refer:
- to normal usage conditions with separated products (detergents, salt, rinsing product).
- *only to multifunction product usage conditions*

They may vary depending on the load, the water temperature, the softener setting, the presence of rinsing product and the supply voltage.

EN 10/ WASHING PROGRAMMES





Fig. 02

Advice:
Consult the Programmes table on the preceding pages to determine the programme you

• *Immediate starting of a programme*

Press "**On**/Off" Ⓐ to switch on the appliance.
Select a programme by pressing any button ⟨ ⟩, or the **"ICS"** button if using automatic programming.
When a programme is selected the relevant light comes on.
Press **"Start**/C" Ⓕ, the 'current' light ↦ comes on and the programme starts.

Programme end time:

Time remaining in programme:



Advice:
A short audible signal (beep) confirm the button's selection, except for the "On/Off" button.

• *Delayed start of a programme*

Delay a programme by 1 to 12 hours by successively pressing or holding down the **"Delayed start"** button Ⓔ.
Confirm by pressing **"Start**/C" Ⓕ.
The screen counts off the hours to the start of the programme.

Waiting for delayed start

Programme end time:

Time remaining in programme:



End of programme:



• *Cancelling a programme*

Press "Start/**C**" Ⓕ for a few seconds

• *Switching off the appliance*

When the programme is finished, press "On/**Off**" Ⓐ .

end time

time remaining

panel lock

• *CLEANING THE WASTE FILTERS*

The filtration system consists of several elements:

Ⓐ - **The waste filter**

Ⓑ - **The large main filter**

Ⓒ - **The micro filter**

The filters are located in the centre of the tub and must be washed regularly to obtain optimum washing results.

Actions :

① Before removing the filters, remove any waste on the large main filter Ⓑ with a sponge so that the waste does not block the sprinkler arms. Rotate the spray Ⓓ arm as shown in the drawing. (Fig. 14)

② Loosen the waste filter a quarter of a turn and then remove it Ⓐ

③ Remove the main filter Ⓑ

④ Remove the micro filter Ⓒ



Fig. 14

⑤ Carefully clean filters Ⓐ, Ⓑ and Ⓒ under running water (Fig. 15)



Fig. 15

Re-installation:

Proceed in reverse order, inserting filters Ⓒ and Ⓑ and then Ⓐ

Important :

Remember to lock the waste filter Ⓐ in place by pushing it in fully and turning it a quarter turn.

EN 12/ CLEANING YOUR APPLIANCE

• *Periodically :*

Every 3 or 4 months, in order to remove any deposits, run a special maintenance programme, without any items in the machine, using a commercially available special dishwasher cleaning product.

Important :
Keep this product out of children's reach..

• *Prolonged stoppage*

Clean your dishwasher completely and then unplug it from the electricity supply and close the water tap. Protect your machine from potential frosts

Advice :
Do not use abrasive powders, metal sponges and alcohol-based or thinner-based products. Use a cloth or a sponge.

If you are moving house, run a soaking programme first of all, in order to avoid any water escaping.

• *Cleaning and upkeep of your appliance*

To keep your appliance in good working order, we recommend that you use **Clearit** household products.

Professional expertise for the general public

Clearit offers you professional products and adapted solutions for the daily upkeep of your household and kitchen appliances.
You may find them in conventional retail outlets, along with a complete line of by-products and consumables.

• *SAFETY SYSTEMS*

• *Door not properly closed*

The 'Underway' light ⊢→ comes on when the door is not properly closed.

• *Programme access lock*

Throughout the period the programme is running, or the full duration of the programme, the programme selector and the buttons are automatically protected from any kind of manipulation. This unlocks automatically at the end of the programme or when the programme is cancelled by holding down the "Start" button for 3 seconds.

• *Advice on cleaning the filters*

Approximately every month, your dishwasher advises you to proceed to service the filters (see Section "Cleaning the waste filters" - Fig. 14-15).

• *Anti-overflow system*

This system activates the drain pump automatically if the water in the tank reaches an abnormal level.

• *Anti-leak protection system*

This system cuts off the water supply if a leak is detected under the appliance.

• *Total safety*

This supply pipe is fitted with a device to cut off the water supply directly at the tap if there is a leak.

• *The warning light* ⚠

Error in programme or incident (refer to para 14 'Operating faults').

- If there is a fault, the display will show the fault code:

• SUMMARY OF THE FAULTS

⇩ Flashing LED(s)	⇩ for models without a display ⇩		Flashing LED(s) ⇩
●○○○	**d01 :** water supply fault (tap)	**d07 :** overflow / anti-leak fault	●●●○
○●○○	**d02 :** draining fault	**d08 :** sprinkling distribution fault	○○○●
●●○○	**d03 :** heating fault	**d11 :** pressure sensor fault	●●○●
○○●○	**d04 :** temperature fault	**d12 :** filling fault (water inlet detection system)	○○●●
●○●○	**d05 :** faulty motor	**d13 :** faulty heating	●○●●
○●●○	**d06 :** faulty motor	**d14 :** pump filling fault or insufficient flow from the water tap.	○●●●

Tip:
If one of the above faults occurs and you need to call a repair man, remember to tell him the message displayed (d01, d02..) as this information will help him.

• BEFORE CALLING FOR SERVICE

Problem	*Possible causes*	*What to do?*
The door falls heavily when opened (integratable model)	- Door springs not tensioned enough to compensate for the weight of the panel.	- Tighten the two tensioning screws accessible in the bottom section above the front feet.
The door does not stay horizontal when open or returns too quickly (integratable model)	- Door springs tensioned too much. - No wooden panel.	- Loosen the two tensioning screws accessible in the bottom section above the front feet. - Fit a temporary wooden panel on the appliance and adjust the springs.
The door catches when closing	- Appliance not stable - Door not centred on the tub	- Adjust the feet. - Re-centre by adjusting the rear feet.
The upper basket does not stay in the high position	- Poor manipulation (the basket is being pulled upwards too quickly)	- Act more progressively (see instructions), one side and then the other.
Small leak around or under the appliance (move the appliance to locate the leak)	- Leak from the tap. - Leak from the appliance. (Cf. table fault d07).	- Check that a seal is fitted and retighten the nut. - Close the water tap and call a technician.
Small leak at the door	- Appliance not stable or not level - Door not centred on the tub.	- Adjust the feet. - Re-centre by adjusting the rear feet.

• THE INDICATOR LIGHTS

Problem	*Possible causes*	*What to do?*
The salt light does not go out	- No salt or an insufficient quantity of salt in the tank to trigger the float.	- Refill the tank and wait for the cycle to end. If you have soft water that requires no salt, the light is constantly lit.
The lights all light up one after the other	- Wrong programme.	- Cancel the current programming by holding down the Start button for 3 seconds and then re-programme.
A light flashes and the programme does not start	- Programme selector wrongly positioned (between two notches)	- Reposition the selector on a programme.

• RELATING TO PROGRAMMING, DISPLAY

Problem	*Possible causes*	*What to do?*
The cycle lasts too long	- The energy-saving programmes last longer because the agitation and drying times are longer to compensate for the lower washing and drying temperatures	- Use these programmes preferably at night when it is not so important how long the programme lasts or when it ends.
The appliance trips the circuit breaker	- Insufficient amperage to supply all the appliances being operated simultaneously. - Internal fault in the appliance.	- Check the socket's amperage (10A minimum) and the meter's capacity. - Call a technician.
The appliance does not start	- No mains power to the socket. - Tap closed (Cf. table fault d01). - Water supply hose kinked. - Selection error or programme blocked. - Start button pressed too long (greater than 2 secs). - Appliance in Safety mode (anti-leak) (Cf. table fault d07).	- Check the socket and the fuse - Check the tap is open. - Check the hose line is OK. - Cancel by holding down Start for 3 secs and re-programme. - Just press Start briefly to start the programme. - Call a technician.

Problem	*Possible causes*	*What to do?*
The appliance will not restart	- Door opened during a washing cycle.	- Wait for the time delay to end (controlled internally by the appliance).
The appliance does not drain (Cf. table fault d02).	- The cover has not been removed from the sink's U-bend. - Drain hose kinked. - Filters totally blocked. - Pump blocked.	- Remove the cover. - Check the drain hose line behind the machine is OK. - Remove and clean the filters and the drain. - Initiate a Soaking programme If the fault persists, call a technician.

• *POOR WASHING RESULTS*

Problem	*Possible causes*	*What to do?*
Food traces and deposits in the glasses	- Items poorly arranged (masked by another larger item or situated underneath it, items nested or jammed together). - Upper spray arm blocked by cutlery or a dish etc. - Filter poorly locked and lifting during washing. - Micro filter screen clogged. - One or more holes in the spray arm blocked.	- Arrange the items properly. Use the most appropriate areas and accessories for each type of item (see instructions). - Check that the spray arm rotates freely. Set the basket in the high position if necessary. - Check the filter's facing and that the filter is locked in place (push it in fully, turning it to the right). - Remove all the filters and clean them (in warm water), including the micro filter's screen (once a month). - Remove the spray arm by turning the lever a quarter of a turn and clean it under the tap (do not use any tool that could damage the holes). Re-install the spray arm.
Traces of grease	- Detergent dose too low; inefficient detergent; stale product. - Inappropriate programme (temperature too low; duration too short).	- Increase the dose; try another detergent. - Select a programme with a higher temperature.

• *POOR WASHING RESULTS...*

Problem	*Possible causes*	*What to do?*
White marks (identify what type)	- Chalky film (removable with vinegar). - Traces of salt (items have a salty taste).	- Check that there is salt in the tank (light unlit = OK). - Check the water hardness at the tap and that the water softener is set correctly. Adjust it to a higher level if necessary. - Water too hard for using a “4-in-1” detergent without the addition of salt. - Check that the stopper on the salt container is closed correctly.
White marks (identify what type)	- Glass cloudy because water too soft (cannot be removed).	- Check the water hardness at the tap and that the water softener is set correctly. Some detergents in pellet form are more aggressive to glasses and decorations (change the product and use a protective product if necessary).
Coloured marks (tea, wine, coffee)	- Items poorly arranged - Detergent dose too low; inefficient detergent - Programme temperature too low. - If you use a multifunction product.	- Turn the cavities in the items towards the jets. - Increase the dose; try another detergent. - Select a more suitable programme with a higher temperature. - Use the “4-in-1” option (depending on the model).
Streaks or dried droplets on glasses	- Lack or insufficient amount of rinsing product. - Rinsing product out-of-date or inefficient. - If you use a multifunction product.	- Check the indicator light and fill the tank completely. Adjust the dispensing unit to a higher position if necessary. - Use a recent product (a good product dilutes easily and foams in cold water). - Use the “4-in-1” option with a setting prioritizing drying (parametering from the menu – depending on the model).
Dried-on marks on glasses, dullness.	- If you use a multifunction product.	- Use the “4-in-1” option with a setting prioritizing brilliance (parametering from the menu – depending on the model).

• POOR OPERATION

Problem	*Possible causes*	*What to do?*
Constant filling A lot of waste on the large filter at the end of the cycle.	- Drain hole situated too low for the appliance (Cf. table fault d012). - The filters and drain outlets are blocked with too much residue.	- Drain wand has fallen on the floor. - Remove and clean the filters and the bottom of the drain outlets. Remove large residue from the plates before putting them in the machine.
Traces of rust on stainless steel	- Quality of the stainless steel ; not dishwasher-safe (knives in particular)	- Use “special dishwasher-safe” cutlery. - Check that the lid on the salt container is closed correctly.

• POOR DRYING RESULTS

Problem	*Possible causes*	*What to do?*
A lot of droplets on the glasses	- Lack or insufficient amount of rinsing product. - The dose has not been distributed. - Positioning of the items.	- Check the indicator light and fill the tank completely. - If the tank is not empty after approximately 60 washings, call a technician. - Arrange the items to restrict water retention as much as possible. Leave the door ajar for a few minutes, if possible
Droplets on plastic items, Tefal coatings, etc.	- These items have a low calorific mass.	- Arrange the items in the upper basket.
Poorer drying on rapid programmes	- On rapid programmes, the drying temperature and drying period are reduced to cut down the duration of the cycle as much as possible.	- Leave the door ajar for a few minutes.
Condensation on the wall of the inside door or the tub.	- Condensation may form on the walls, particularly after the appliance has cooled down (sound insulation increases this occurance)	

• *CHANGING THE BULB*

You can change the bulb (halogen type G4-12V-5W) located on the left under the top cover. To do this:

Important :
Unplug the power cable before changing the bulb.

(depending on the model)

– Remove the top cover by unscrewing the two screws under the top cover's lip (Fig. 16 A).

– Remove the top cover by unclipping it from the back of the appliance and then pushing it a few centimetres (Fig. 16 B).

– Lift off your dishwasher's top cover (Fig. 16 B).

– Remove the 2 top screws from the protective plate and remove the plate (Fig. 16 C).

Important :
For safety reasons, do not touch the two other screws.

– Open the cover by pinching the 2 clips (Fig. 16 D).

– Remove the bulb/bulb holder assembly from its housing (Fig.16 E).

Important :
Use a soft cloth to manipulate the bulb.

– Change the bulb by freeing it from its housing (Fig.16 F).

– To re-install the bulb, follow the above instructions in reverse order.



Fig. 16

• *INTERVENTION WORK*

Any intervention work on your appliance must be performed by a qualified professional approved by the manufacturer. When you call, please mention the full reference for your appliance (model, type and serial number). This information is shown on the description plate (see Fig. 17)

ORIGINAL PARTS

When maintenance is being carried out, ask for only certified original spare parts to be used.



Fig. 17

EN 15/ INDICATIONS FOR THE TESTING LABORATORIES

• *Details common to all models*

– Washing capacity ---------- 12 standard place settings
– Arrangement of the items ---------- Figs. A-B-C; see next page
– Loading as per the indications on next page, without side shelves
– Setting for upper basket ---------- Low position
– Setting for rinsing product distributor ---------- 3
– Adjusting the water softener ---------- H2

For detailed information on the comparison tests regarding the level of soiling, the types of crockery and cutlery, etc., contact the equipment manufacturer before commencing the tests.

• *Tests to Standard EN 50242:*

– Recommended programme ---------- WASH
– Dosage of detergent ---------- 30g of detergent B

• *Tests according to the mixed IEC 436/DIN 44990 method*

– Recommended programme ---------- **"Eco"**
– Dosage of detergent ---------- 5 + 25g.

NB: When conducting tests using a multi-function tablet: H0 or H1 or H2
- Check that the water softener is correctly set for the water hardness
– Pull out the detergent distribution drawer and place the tablet in the interior compartment.

• *Measuring the noise level in accordance with Standard EN60704-2-3:*

– Align the plinth on the housing unit with the door panel.


A
B
1 2 3 4 5 6 7 8
NOK
NOK
OK
C

EN NOTES

EN NOTES

EN After Sales Service:

Any maintenance on your equipment should be undertaken by:
- either your dealer,
- or another qualified mechanic who is an authorized agent for the brand appliances.

When making an appointment, state the full reference of your equipment (model, type and serial number). This information appears on the manufacturer's nameplate attached to your equipment.

FR Service après vente :

Les éventuelles interventions sur votre appareil doivent être effectuées :
- soit par votre revendeur,
- soit par un autre professionnel qualifié dépositaire de la marque.

Lors de votre appel, mentionnez la référence complète de votre appareil (modèle, type et numéro de série). Ces renseignements figurent sur la plaque signalétique fixée sur votre appareil.

DE Kundendienst :

Eingriffe an Ihrem Gerät dürfen nur:
- von Ihrem Händler oder
- von einem sonstigen Fachmann und Vertragshändler der Marke durchgeführt werden.

Geben Sie bei der Meldung einer Störung die vollständige Typenbezeichnung Ihres Gerätes an (Modell, Typ, Seriennummer). Diese Angaben finden Sie auf einem an Ihrem Gerät angebrachten Schild.

ES Servicio postventa :

Las intervenciones que requiera la máquina deberán ser efectuadas:
- por el revendedor,
- o por cualquier profesional cualificado depositario de la marca.

Al llamar, mencione la referencia completa de la máquina (modelo, tipo y número de serie). Estos datos figuran en la placa de identificación situada en la máquina.

PT Serviços autorizados :

Qualquer intervenção no seu aparelho deve ser realizada:
- quer pelo seu revendedor,
- quer por outro profissional qualificado autorizado pela marca.

Ao chamá los, indique a referência completa do seu aparelho (modelo, tipo e número de série). Estas informaçõe figuram na placa de identificação fixada no aparelho.

DA Kundeservice :

Eventuel vedligeholdelse af apparatet skal foretages:
- enten af Deres forhandler,
- eller af en kvalificeret fagmand, som er anerkendt til dette mærke.

Når De ringer op, skal De angive apparatets fulde reference (model, type, serienummer). Disse oplysninger står på typeskiltet, der sidder på apparatet.

NL Serviceafdeling:

De eventuele ingrepen in de machine moeten worden uitgevoerd :
- of door uw vakhandelaar,
- of door een andere gekwalificeerd technicus van dit merk.

Tijdens het telefoneren, dient u de complete referentie op te geven van uw machine (model, type, serienummer). Deze informatie staat op het typeplaatje op de machine.

PL Usługi serwisowe :

Wszelkie czynności serwisowe wykonywane na urządzeniu muszą być wykonane przez:
- sprzedawcę,
- wyspecjalizowany zakład naprawczy posiadający atest producenta.

Aby przyspieszyć i ułatwić obsługę prosimy o podanie dokładnych danych dotyczących urządzenia (model, typ, numer seryjny). Wszystkie te dane znajdują się na tabliczce znamionowej umieszczonej na urządzeniu.

CS Záruční servis:

Případné opravy na přístroji může provádět pouze :
- váš prodejce
- nebo záruční opravna, která má smlouvu s výrobcem

Při telefonickém styku uvádějte úplné označení vašeho přístroje (model, typ a výrobní číslo). Tyto údaje jsou uvedeny na výrobním štítku přístroje.

RU Сервисное обслуживание:

При необходимости ремонта Вашей машины, он должен производиться:
- либо тем, кто ее продал Вам;
- либо специалистом, имеющим квалификацию по ремонту данной модели.

При обращении в службу ремонта укажите все данные Вашей машины (модель, тип и серийный номер). Эти данные указаны на идентификационной табличке, закрепленной на устройстве.

EL Τεχνική υποστήριξη:

Οι ενδεχόμενες επεμβάσεις πάνω στη συσκευή σας θα πρέπει να διενεργούνται:
- είτε από τον προμηθευτή σας,
- είτε από το κατά τόπους εξουσιοδοτημένο σέρβις.

Σε περίπτωση που τηλεφωνήσετε, θα πρέπει να αναφέρετε όλα τα στοιχεία της συσκευής σας (μοντέλο, τύπο και αριθμό σειράς).Τα στοιχεία αυτά αναγράφονται στην ετικέτα των χαρακτηριστικών του κατασκευαστή που βρίσκεται πάνω στη συσκευή.

B4831-B-05/07

Brandt Appliances - SAS au capital de 10.000.000 euros - RCS Nanterre 440 302 347

Photographie de couverture/front cover photography: Michel Gibert

DVH742,-